

Fold-up bill wallet / Arches

Flat 5.80 x 5.20 in · Folded 4.90 x 2.35 in · Fits bills up to 4.00 x 1.75 in

Print on letter paper at 100% scale. Switch off "fit to page" or the wallet comes out undersized. Card stock holds up best.



Assembly

- 1 Cut along the solid outline.
- 2 Score and fold every dashed line the same direction, away from the printed side.
- 3 Fold the back panel behind the front. The middle fold becomes the base of the pocket.
- 4 Fold both glue tabs forward and tape or glue them to the front panel edges.
- 5 Slide bills in the open top; tuck the flap inside to close.